

SMARTSTART®

SSI-2035 User Manual



Copyright © 2018

Ei taropwe mi nom fan tumwunun ika eppetin ennukun copyright me etipeew meren chomongun mwuu iwe ekkei masowen non a fis pwun pisekin Smart Start, LLC. Om copyni, nounoun, me einet ei taropwe, ika kinikinin ei taropwe epwe tipis meren kopwung. Smart Start ew an Smart Start, LLC trademark. Meininis trademark e nounou seni iei a fat pwun pisekin ika a nom fan nemenien ekkewe owner iwe ra nounou ika aa faniten chok ar repwe tongeni ID.

Disclaimer

Chon makkei ei taropwe iir mei wanong unuseochun ar angang ar repwe amonata ekkei porous pwan foreochu pwun masowan meininis epwe pwung non ewe fansoun a print ei taropwe. Esapw tipisin Smart Start LLC. ika pwun e mwanino osukosuken tech iwe mei pwan nonom rer ewe pwung ar repwe ekesiwini, eochuweno, pwan asokonoi kokotun ekkewe program me ekkei taropwen kait nge ese pwan esinesin ngeni aramas, ofes, ika kumien aramas ren ekkei ekkesiwin.

Smart Start, LLC.

Note: Kose mochen anneani me sainei ena form nesokurun ena puuk iwe ka eniwini ngeni minne ra masamas won.

Contents

FCC Statement.....	4
Pekin Tumuneoch.....	5
Handset Mount.....	6
Mouthpiece Cover	6
Tutumuneochun om Enimenima.....	6
Pwan Ekkoch Mettoch Kopwe Tumueoch fanitan.....	6
Tichikin Porusan.....	7
Tetenin Parts.....	7
SSI-2035 Operations.....	8
Kamasen Mouthpiece.....	8
Nenien Ewe Head Unit.....	9
Pinepinen Mouthpiece.....	10
Ifa Ussun Om Angei Test.....	11
Pwungun Test.....	11
Met A Fis Mwirin Test.....	11
Re-Tests	12
Lockouts	13
Code-un Unlock.....	14
Messagea Pichitame Angangen Troubleshoo.....	15
Maintenance	17
Service me Calibration.....	17
Mwomwonenon ei pisek.....	17
Spea me Pisekisekin.....	17
Service me Aninis.....	18
Aninis ngeni Kastomer.....	18
SSI-2035 Service	18
Service Mi Kawor Mwirin Kunokun Kesip.....	18
Nenien Aninis	18
Technical Data.....	19
Ignition Interlock Client Checklist.....	20
Annea oh pwan Weweiti.....	21

Figures

Figure 1 HeadUnit/Chamwan.....	7
Figure 2 Kamasen Mouthpiece.....	8
Figure 3 Keyen Mouthpiece.....	8
Figure 4 Ew Mouthpiece mi Pwungupwungeoch an Pwurenong.....	9
Figure 5 Chamwan a pachengeni ewe Mounting Clip.....	9
Figure 6 Chamwan mi pacheta ewe Pinepinen Mouthpiece.....	10

Tables

Table 1 Message Mi Pichita Me Kaitin Troubleshoot..	16
Table 2 SSI-2035 Specifications	19

Statementin FCC

Ei pisek a test iwe mei fiti kounkun me ennuhun pisek e nom faan ewe Class B digital device mi fiti ennuh Part 15 me non ekkewe ennuhun FCC. Ekkei kounkun a foruta faniten epwe wor eppetin met mi efeiengaw an epwe osukosuka an pachapacheta. Ekkei pisek mi tongeni awora osukosuk me non radio ika pwun ese pwung pachapachetan, ese fiti met mi kait. Nge, eseor eppetin an esapw fis ekkei osukosuk. Ika pwun ei pisek mi osukosuka radio me tv, minne kopwe tongeni sinei om ka offei me onnei ei pisek, en minne omna pisek kopwe opwungu nounoun ei pisek ren om kopwe:

- Siwini ika awenaeochu ena antenna
- Atowawa ewe pisek seni ena receiver
- Asokonoi menni outlet e pwureta ena pisek won seni menni ena receiver e pwureta won.
- Churi ewe minne chon pacheta om na pisek ika emon chon fori radio/TV an epwe anisuk.

Ikkei met mi katour seni FCC mi pwan tongeni anisuk: “Ifa Ussun om kopwe Kuna Me Fori Osukosuken Radio-TV seni ei Pisek.” Ei kukun pwuk a kawor seni ewe U.S. Government Printing Office, Washington, D.C. 20402.

Ekkesiwin e for nge ese mumuta meren chon fori ei pisek mi angeisonuk om mumuta ne pipisek ei pisek fan ekkewe ennuhun Federal Communications Commissions.

Safety

Fiti fichi met pi tichikitiw ren pekin kaitin om aa. Om aa ei pisekin SSI-2035 mi menei om weweochuti me tumuneochu metekei mi kait ngonuk. Nounoun ei pisek epwe chok fiti met mi maketiw me non ei manual.

Om asokonoi nounoun ei pisekin SSI-2035 mi tongeni atai ei pisek. Om pwan asokonoi nounoun ei pisek mi atai ennukun me aninisin tumwunun mi kawor faniten ei pisek.

Om kopwe tumuneoch ika eppet i om fiifi me an epwe kar, tumunu pwun epwe pacheoch meinisin pisekin ei SSI-2035. Kosapw fichi saan mi sangeni ena SSI-2035 pwun mi tongeni awora om kopwe fiifi ika efisata och kar.

Pachapachen ei pisek epwe chok feito seni ekkkan minne chon fori me non ekkewe Smart Start, LLC Service Center ussun met mi affatetiw me non ekkewe listin kait faniten pachapachen ei pisek. Servicin me maintenance ika tumwunun ei pisek epwe chok feito seni ekkewe iir mei angangen ar repwe fori ei pisek.

Osukosuken an ese chiwen eoch ika fen taan ei pisek a fis pwe tipisin minneka pisekin ei, ika pwun e wano epwe for meren ekkkan esapw ururun chon fori seni Smart Start, LLC me ika ena pisek ese pwung nounoun.

Kosapw pachei ena interlock ian epwe mecheres me ta me ie: faan, fan om ashtray, ika ian kosapw kuna me rong okurangan me ia. Kosapw pwan anomwu ian epwe wich ika chochon me ia. Ika epwe ta ei pisek faniten om tumunungaw ngeni, a tipisum.

Kosapw angengeni kokotun ei pisek. Ika pwun ke fori ei mettoch, epwe pwan wor sopusopun om osukosuk me kapachetan tipisum meren kopwung iwe epwe pwan wor esinesin ngeni minne chon masamas wom.

Esapw tipisin Smart Start LLC ren om rongongaw me kose fiti met mei eureur ngonuk faniten aan ika nounoun ei pisek. Provision faniten warranty me liability ren kamon me katourun meren Smart Start, LLC ese pwan fitingeni eureur mi afatetiw asan.

Handset Mount

Mi kaworngonuk ew handset mount om kopwe tongeni annomwu ei pisek ian epwe mecheres om kopwe tikeri me ia, pwan ia esapw mecheres ta me ie. Ika pwun ei mount a need epwe ekesiwin, kokori ewe epwe tongeni servicini ar repwe ngonuk efoch minafo.

Pinepinen Mouthpiece

Ena Pinepinen Mouthpiece a kaworngonuk faniten epwe pineseni ewe Mouthpiece nimengaw seni pwun ika chochon. Ika pwun kose aa ewe mouthpiece pacheta ena pinepinan.

Tumwunun Nimeniman

Achochonu echo mangaku pwan sopwuni ekis iwe ka taunei nukun chok ei pisek. Kosapw aa arukor me met monukun met mi afatetiwi kopwe aa pwun mei tongeni ta ei pisek ren. Ekkei Mouthpiece mei tongeni soopw iwe kapwan aa sefan. Iteiten om test kopwe aa ew mouthpiece mei pwas me nimenimeoch.

Pwan Ekkoch Pekin Tumuneoch

- Aa ika nounou ei pisek ren met chok mi afatetiwi ururun nounoun ei pisek.
- Kosapw uun sakau, mongo mettoch mei wor sakau ika arukor non, ussun chowan safei, me okasi, me kokoon non awom ika mouthwash mei wor arukor non 15 minich mwemwen kopwe angei test. An wor arukor me non awom mi tongeni siwini me angawano pwungun om test.
- Kosapw achochonu ika otukanong ei pisek non konik.
- Kosapw nounou ei pisek ika pwun ke kuna nge ese pwung ika afen ta ika pwan ke oturatiwi ika epwan turunong non konik.
- Monukun me won ewe mouthpiece, kosapw wanong mettoch ekis tefen ei pisek.
- Kosapw aa sokun spray meinisin ian epwe wo ia oxygen.
- Kosapw anomwu ei pisek ian epwe kon tineiti ia akar, kosapw pwan akanangeni ian epwe pwichikar me ie. •Kosapw akanangeni semirit.

Kokori 1-800-880-3394 faniten repair me service.

Tichikin Porousan

Ewe SSI-2035 ew ignition interlock device e kuna arukor non an aramas angasangas, mi menei an aramas repwe angei ei testin angasangas an epwe tongeni ammanaw war chitosa. Ika pwun e nuseni ururun koukun arukor epwe nom non inisin emon aramas, ese tongeni ammanaw ena chitosa. Ekkewe chok e kukun fan ewe koukun arukor non inisin aramas e tongeni amanawa ena chitosa.

Ei pisekin ignition interlock ese osukosuka om engine, ese pwan tongeni offeno om engine ika a fen ammanaw.

Ese nifinifin ion epwe tongeni uwei wom chitosa, nge nupwen a pach ei pisek, meinsin chon uwei repwe angei ei test, iwe en ka pesepes won meinsin pwungun ar test.



Figure 1 Chamwan

Listin Parts

Ikkei ekkei parts won ei SSI-2035:

- Ei pisek SSI-2035
- Mouthpiece
- Nenien Mount ren Chamwan
- Pinepinen Mouthpiece

SSI-2035 Operations

Pachapachetan Ewe Mouthpiece

Mei wor neien ewe mouthpiece me won ei SSI-2035. Ew chok ititin ena mouthpiece an epwe tikenong.



Figure 2 Pachapachetan Ewe Mouthpiece

Fatiwen ena Mouthpiece me nepekin mi wor ena key. Pachei ena key ngeni ena slot nenian won ena SSI-2035, ka pachei tori an pwurenongoch won ena inisin 2035.



Figure 3 Keyen Mouthpiece



Figure 4 Mouthpiece Mi pwung Pwurenongan

Mounting Clip nenien Chamwan

Ena Mounting Clip sikan aa ach pacheta en Chamwan won en dashboardun chitosa. Ei e fori an epwe:

- Anomwu ewe Chamwan non ew neni epwe mecheres ngeni ewe chon unteng
- Nom non ew neni epwe mecheres ach kuna me rong.
- Tumuneoch ei pisek

Ekkei mettoch meinisin mi euehea om kopwe ekieki nupwen ka fini ian epwe nom ia ei pisek.



Figure 5 Chamwan an a nom won Mounting Clip

Pinepinen Mouthpiece

Mi wor ei pinepinen mouthpiece me won ei pisekin SSI-2035 an epwe eppeti ewe mouthpiece seni taas, nimengaw, me chochon. Ika kose aa ei mouthpiece, ei pinepinan epwe chok nom won fansoun meinisin.



Figure 6 Chamwan nupwen ewe Pinepinen Mouthpiece a Pacheta

Ifa Ussun om Angei Test

Ika pwun en chon unteng nge ke ngeni emon epwe angei om test, mi atai enukun ena program ke nom won. Omna mouthpiece epwe nimeoch anein mwemwen om test.



Mwemwen kopwe angei test:

1. Uun KONIK mwemwen ew me ew test. Ei mi anisi ne nimetau masowen awom epwe tongeni osukosuka test.
2. Kosapw aa apokusun non aaw pwun ekkei metoch mikan watte arukor non.
3. Kopwe NGASENONG mwemwen kopwe test.

1. Amanawa ena chitosa. A onneta na pisek iwe a mak PLEASE WAIT. Non ei atun, ena pisek a enukunukun test. Non ei fansoun, ka uun KONIK om kopwe animau non awom.
2. Ika a mwonengeni test, ina epwe pichita BLOW.
3. Ka chok tongeni angei ena test ika pwun a pichita ena mak BLOW; kose tongeni test mwemwan.
4. Etatiw ewe pinepinen mouthpiece.
5. Ngasonong mwirin ka ngasou, eukuu ngeni 4 seken.

Om ka mina omna test, ina epwe kan pichita TEST.

6. Sopweno ne usi won ena mouthpiece tori epwe tik iwe a mwuch tikitikin.
7. Ika pwun ese pwung taimen om angei ena test, ina epwe pichita wewen ese pwungupwungeoch omna test. Ekkei mi afatetiw me nonewe kinikin, Met a Fis Mwirin Test.
8. Ika pwun a wes om na test nge mipwung aan ena test, ina epwe pichita ANALYZING non ekis fansoun nupwen ena test a checkii ewe samplun om angasangas ka wanong.
9. Mwirin om angei ena test, pachesefani ewe pinepinen mouthpiece won ena mouthpiece iwe eniwinata ena pisek won ewe mount.

Pwungun Test

Ika a mwuch checkin ewe test, ew me nein ekkei epwe pichita:

1. PASS wewen nge ka tongeni amanawa women chitosa.
2. WARN ina epwe pichita iwe ka tongeni amanawa womna chitosa.
3. FAIL wewen kose tongeni amanawa women chitosa.
4. VIOL(lation) wewen kose tongeni amanawa womna chitosa.
5. Ren ew test ese pwung taiman ika e kon mwochomwoch, wewen mikan pichita nge kose tongeni pwan amanawa womna chitosa.
6. Ika a ammanaw womna chitosa, mi pichita efou (*). Wewen ei, ei pisek mi kuna pwun a manau womna chitosa.

Met A Fis Mwirin Test.

Ika pwun e Incomplete om Test ika ke FAIL, kopwe angeisefanni pwan ew test nge kopwe pass an epwe tongeni manaw womna. Ika pwun kose passini ena test ina epwe pichita FAIL, mwirin epwe pichita PLEASE WAIT, iwe a pwan pichita BLOW. Wewen epwe Incomplete om Test:

•**BLOW SOFTER** - Ika pwun kekon omwuch ne usi ena mouthpiece, kopwe okukunatiw pochokunen om angasangas.

•**BLOW LONGER** - Ika pwun ekon mwochomwoch fansoun om usi ika angasangas, kopwe ekis atamano ika awateno met ke angasangasa.

•DON'T INHALE - Ena pisek mi tepereni pwun kefen eniwini enienin om angasangas, ika ke ngaseta napseni om ngaseu. Napengeni ei mak a pichita mwemwen epwe pichita BLOW won ewe pisekin test nge ewe chon aa e ngaseta nge awan ekon kanengeni ewe mouthpiece.

•PLEASE RETRY - Ei pisek ekon wich ika mi wor chochon faniten om aa fan chomong ei test, mi tongeni pwan pichita ika pwun e wor met e osukosuka ika epeti ewe vent nukun sokurun Chamwan ewe 2035 - Ewe chon test epwe awora fansoun ne nimeti metena e chochon ika wich ika osuu met e epeti ewe vent.

Test Sefan



Mwemwen kopwe angei test:

1. Uun KONIK mwemwen ew me ew test. Ei mi anisi ne nimetau masowen awom epwe tongeni osukosuka test.
2. Kosapw aa opokusun non aaw pwun meikan watte arukor non.
3. Kopwe NGASENONG mwemwen kopwe test.

Ika a manaw wom chitosa, ena test ina epwe esinengonuk kopwe test sefan nupwen a piip a pwan pichita ewe mak BLOW fitifengen me an pichita time-an. Ena timerun re-test epwe ngonuk koukun time kopwe tongeni kouno pen aan om kopwe angei sefani om test. Ika pwun kose angei ew re-test, ina ewe pisek epwe afata pwun MISSED TEST.



TUMUNEOCH! En mi pwan tikingaw ika pun kose angei rew re-test, mei pwan isois porousen om kose angei om re-test me non ei pisek.



TUMUNEOCH! Om nounou ei pisek, anneasosich ngeni ennukun unteng, tumuneoch non om unteng me katoneoch aan.
Kopwe kutta ew neni minne kosapw osukosuk ia mwemwen kopwe angei ena retest.

Kosapw offeno womna chitosa. Kopwe angei ena test mwemwen kopwe offeno wom chitosa, ika kose iwe ina epwe pwan nom non tikin tikingaw.

Foreochu pun ewe Chamwan epwe nom won ewe mount nge epwe sapasapeoch om kopwe kunaechu ekkewe mak ekan pichita. Ika pwun mei okurang noumw music me om asamwacho mi riifetiwi nukanapen om unteng, ina epwe weires om kopwe rong an ekurang ewe pisek ika pwun epwe esinesin nge en mei need ne angeisefanni test.

Nge mei wor tengki ika mak ekan pichita won ei pisek faniten epwe anisi ion ekan weires an rongorong.

Mwirin om angei ew re-test, pachesefani ewe pinepinen mouthpiece won ewe mouthpiece iwe eniwini ewe pisek ngeni ewe mount ekan nom won.

Lockouts

Ussun met mei afatetiwi non enukun ei state, mei chomong met epwe tongeni fori an ei pisek epwe lockout. Ikkei ekkei sokopaten lockouts mi atetenitiwi fanei.

Mei kan kawor fansoun mwemwen epwe wessen lockout ei pisek, nge ei koukun time mei sokono meren ew me ew state.

Anein epwe wor om tikingaw, epwe kaimwu 1 seni ena nampa. Ena pisek epwe lockout iwe kose mumuta om kopwe angei test non 4 nikinik:

1. Ika pwun ew Lockout

Non Mochomochen Fansoun ina epwe pichita ewe mak FAIL / LOCK x:xx:xx. Epwe fis ei nupwen kose passini koukun test mi mumuta kopwe angei. Ei pisek ina epwe lockout non ew mochomochen koukun fansoun. Ei time epwe pichita won ewe pisek a aneitiwi tori a mwuchuno ei timen lockout.

Ekkei lockouts non mochomochen fansoun ekan fis ika pwun kose passini om test mwemwen om kopwe amanawa wom chitosa IKA mwirin om amanawa wom chitosa (retest).

Non ekkei mochomochen fansoun en mi lockout, ewe pisek esapw mutata om kopwe test sefan. Ika a fis ei, awora fansoun kopwe uun konik oh pwan angasangas. Test sefan ika pwun a onnosefan ewe pisek. Test sefan ika pwun a onnosefan ewe pisek.

Non ei fansoun lockout, kosapw utti ewe pisek seni nenian.

Non meinisini state mi wor enukun koukun timen ekkei lockout. Katon tichikin porousan enukun me angangen ekkei lockouts me non ena state ke nom non. Non ekkoch state ew RE-TEST mi eueha kopwe angei non ew fansoun mwirin a mwuch ewe lockout.



Tumuneoch! Ew lockout non mochomochen fansoun mi tongeni need om kopwe uweano womna chitosa ngeni ekkewe nenien service.

2. Lockoutun Service

Ussun met mi pichita ren SvcLckxxday ika SvcLockxxhr. lei ei esinesinen om kopwe tumuneochu servicin om ei pisek non ena koukun raan ika awa nussun mwemwen ewe pisek epwe lockoutofoch fan iten om kose uweano non nenien service non ururun raanin appointment.

Nupwen a pichita LOCKOUT SRVC , wewen a lockoutofoch ewe pisek. Kose chiwen tongeni angei test ika amanawa womna chitosa. Kopwene uwei womna ngeni ew ekkewe nenien service om kopwe angei ew Code-un Unlock. Fan ekkoch, mi kan kamo ekkei code.



Tumuneoch! Kosapw aneangaw ngeni esinesinen tumuneoch me ekkei time mei pichita won ewe pisek!

3. Lockout Violation

Nupwen a pichita LOCKOUT VIOL wewen a fisingonuk ew Lockout faniten Tikingaw. Ei ekan fis ika pwun a mwuch koukun om tikingaw non ew kinikin fansoun nge en mi pwan chok fori met kopwe tikingaw ren.

Ikkei met kopwe tikingaw ren:

- a. Ika om angasangas a kon watte levelun sakau non.
- b. Mei wor re-test kose angei.
- c. Ke amanawa womna chitosa nge kose passini test.
- d. Ke utti ewe pisek nupwen mei on.

Ekkei tikingaw mei anei anein om visit nenien service. Won ena pisek ekan pichita VioLckxxday ika VioLockxxhr, an epwe pwari ngonuk fitu raan ika awa nussun mwemwen epwene lockout fochofoch ewe pisek.

Ika a pichita ei LOCKOUT VIOL, ewe pisek a lockout fochofoch. Kose chiwen tongeni angei test ika amanawa womna chitosa. Kopwene uwei womna ngeni ew ekewe nenien service om kopwe



Tumuneoch! Kosapw emenungaw seni ekkena fansoun mi kawor ngonuk om kopwe nongeni nenien service faniten esinesinen tumuneoch ren tikingaw!

4. Restricted Drive-Time Lockout

Ika a pichita RESTRICTED DRIVE TIME wewen kopwene nom won ew Lockout faniten an epwene Kouk Timen om Unteng. Ekkei ekan chok fisingeni ekkewe pisek mi program ar repwe eukuu timen unteng meren minne chon mesemes won ena chon unteng.

Non ei atun lockout, ei pisek ese chiwen ngonuk om mumuta om kopwe angei test me amanawa womna chitosa.

Ika pwun ena pisek e lock out ika ese pwungupwungeoch om nounou, sia tungor kopwene koko sein tow epwe uwei womna chitosa ngeni menni nenien Smart Start e kanengonuk.

Ika pwun e pwa nge ewe osukosuk e feito seni an ngaw ewe pisek, aipwe eniwin ngonuk niwinin om tow-ni womna chitosa ngeni ena nenien service.

Ika pwun e osukosuk nge esapw seni pwusin taan ika ngawen ena pisek iwe kopwe pwusin moni niwinin an tow womna chitosa.

Kose mochen kokori ena nenien service mi kanengeni neniomna ren nampan ekkena kompenien tow non neniom.

Ika pwun epwe nuseni \$100 niwinin an tow womna chitosa, mei EUCHEA kopwe fosngeni emon meinap non ena nenien Smart Start service an epwe fori kokotun womna chitosa an epwe tow.

Code-un Unlock

Mei wor ew aninis faniten om kopwe tongeni Unlockini ena pisek nge kose pwan need sangeni ekkan nenien service ika pwun kose tongeni torii ekena neni. Achewe ofes mei tongeni ngonuk ew code, iwe won ewe keypadin ena pisek, en mi tongeni tikanong ena code.
















Ika ka tikanong ena code, kopwene pwan tongeni nounousefan ewe pisek. Mei euehea kopwe angei me passini ew test mwemwen kopwe amanawa womna chitosa.

Ei code epwe attamano time faniten om kopwe tongeni uweano womna chitosa non nenien service nge non chok koukun onuu (6) awa.

Note: *Ei code echok tongeni kawor ngonuk fan ew.*

Note: *Ei code ese siwini kokotun ei pisek.*

Mak mi Pichita faniten Kaiten Troubleshoot

Mak mi Pichita	Tengki Tichikin Porousan	Angangan
PLEASE WAIT	 Ei pisek mi utiwitin ew testin angasangas	Utiwit tori an pichita BLOW.
BLOW	 Ei pisek a monnota om kopwe angei testin angasangas.	Epwungu ika eukukeochu pwun epwe tam om angasangas ika usienong non ena mouthpiece iwe chemeni pwun mei euecha kopwe pwan MONGUNGU (ika pwun pwan ina ew eureur).
TEST	 Ei pisek mi etiwa om angasangas non ei mouthpiece.	Soposop ne Usi iwe chemeni kopwe MONGUNGU (ika pwun ina met mei pesepepes ngonuk)!
BLOW LONGER	 Ewe samplun om angasangas akon mochomoch.	Angeisefani ena test iwe usimongei ika atama om angasangasonong won enamouthpiece.
BLOW SOFTER	 Akon pochokun om usi.	Angeisefani ena test iwe ekis pwan apwetetei om usi ena mouthpiece.
DON'T INHALE	 Ena pisek a kuna pwun ke ngasonong nge kose fen ngaseu nge en mi kanengeni ena mouthpiece.	Angeisefani ena test iwe kosapw ngasonong pwun kopwe fen ngaseu.
PLEASE RETRY	 E chochon ewe pisek ika e wor mettoch e eppet iwe vent nukunupan.	Utiwit tori an epwe pwasono ena chochon ika omwokutu metena e eppet iwe vent.
PASS	 Ewe sample ke wanong non ena test eseor arukor non ika mei kukun seni koukun arukor mi mumuta.	Ka tongeni amanawa womna chitosa.
VIOL	 Mei wor arukor oh pwan nuseni koukun levelun arukor mei mumuta non ewe samplun angasangas ke wanong non ewe mouthpiece.	Kose tongeni amanawa womna chitosa.
FAIL	 Mei wor arukor oh pwan nuseni koukun levelun arukor mei mumuta non ewe samplun angasangas ke wanong non ewe mouthpiece.	Kose tongeni amanawa womna chitosa..
FAIL LOCK x:xx:xx	 Lockout Non Mochomochon Fansoun faniten a kon tepetep test kose passini.	Kopwe uti tori epwe mwuch ena time mi pichita mwemwen kopwe tongeni test sefan.
SvcLckxxhr	 Ew achechem pwun faniten kose fiti om appointmentin service, ei nampan awa a pichita an epwe achema ngonuk ifa ukukun time mwemwen epwe lockout fochofoch ei pisek.	Kokori ena nenien service e kanengeni neniom om kopwe forsefani ew om appointment an epwe service ena pisekin interlock.
VioLckxxhr	 Achechem pwun faniten om tikingaw, ina nussun time mwemwen epwene lockout ena pisek.	Kokori ena nenien service e kanengeni neniom om kopwe forsefani ew om appointment an epwe service ena pisekin interlock.
APPT MM/DD	 Ew achechem pwun a karap raanin appointment.	Kokori ena nenien service e kanengeni neniom om kopwe forsefani ew om appointment an epwe service ena pisekin interlock.
LOCKOUT SRVC	 Ei pisek a lockout faniten om kose fiti om raanin appointment.	Kokori ena service center e kanengonuk.






Displayed Message	LEDs	Description	Action
LOCKOUT VIOL		Ei pisek epwene lockout fochofoch faniten om tikingaw.	Kokori ena service center e kanengonuk.
RECALL		Mei wor osukosukan ena pisek.	Offeno pwan amanawasefanni womna iwe ka test sefan. Ika pwun mei chok pichita ena mak, kokori ekkena nenien service ika kokori an Smart Start Customer Service.
(Eseor Mak e Pichita - Mei eoch tengkiin)		Ena nenien pichitan mak mei tongeni ta nge ena pisek mei chok epoch.	Sopweno ne angei test ussun om angei akkomw. Kokori ena service center e kanengonuk
(Eseor Mak e Pichita - tengkii apwan ta)		Mei wor osukosukan ena pisek.	Kokori ena nenien service e kanenonguk ika Smart Start Customer Service.
PASS (nge kose tongeni amanawa womna chitosa)		Mei wor osukosukan ena pisek. a	Kokori ena nenien service e kanenonguk ika Smart Start Customer Service.

Table 1 Mak Mei Pichita Me Kaitin Troubleshoot

Ren met om kapaseis, kose mochen kokori ena nenien service mei kanengonuk, Smart Start Customer Service ika nongeni ei peich www.smartstartinc.com iwe ka no ngeni ena Informations fo Clients - Products Support page.

Maintenance

Service me Calibration

Kopwe kan chok wakanong womna chitosa pwun epwe service me forsefan ena pisek. Ikkei met ururun epwe fis:

- Ei angang epwe tongeni chok for meren Smart Start, Inc. Service Center
- Ika pwun a wor esinesinen lockout e mak SvLckxxhr won.
- Ika pwun a tori om appointment.

Smart Start epwe chekii calibration ika angangen me kokotun ewe interlock anein kopwe uweano epwe service.

Koturunon ewe pisek

Kosapw aa pwusin om wewe me pisekin non imwom ika kopwene oturano ewe SSI-2035. Ei pisek epwe ururun niwin ngeni Smart Start, LLC ika ekkewe nenien service mei pwusin kefinita meren Smart Start, LLC. Kose mochen porousngeni Smart Start, LLC Customer Service meren ei nampa 1-800-880-3394 ren tichikin porousan.

Spea me Pisekisekin

- Mouthpiece
- Mount-un ei Pisek
- Pinepinen Mouthpiece

Ika pwun omwe mount a need epwe siwin ika pwun ka pwan need ew minafon mouthpiece ika pinepinen mouthpiece, kose mochen kokori me porousngeni ekkewe chon service.

Service me Aninis

Nampan Customer Service

Porousngeni chon Smart Start Customer Service meren ei nampa 1-800-880-3394 iwe emon aramas mei tongeni anisuk anein fansoun meinisin.

Ika kopwe nikitiv message, kopwe chemeni kopwe pwan nikitativ nampan om area code, nampan noun tengwa, me unusen itom me om lastname pwun repwe tongeni korsefanuk.

SSI-2035 Service

Ina epwe aitngonuk inet kopwe uweanong ena pisek faniten service me calibration. Chechemeni kopwe makketiv raanin om appointment.

Ika pwun womna chitosa mei need service, ureni ekkena chon fori repwe kokori Smart Start ar repwe sinei met repwe fori. Isoni risiit me taropwen kamotiw meren ena saap ke nongeni, epwe afatetiw raan me kunok e toning faniten service pwan raanin me kunokun ka pickup.

Ika pwun mei euehea kopwe pwan ekesiwini patiri me pisekin ammanaw wom womna chitosa, pwan isoni risiitan me taropwen kamotiw minne mi afatativ ena kunokun me raanin re utti patiri fengen me kunokun me raanin ar pacheisefanni efou.

Service Mei Kawor Mwirin Kunok

Ika pwun a tori kunokun kesip nge kopwe kokorikich , kokori ei nampa 1-800-880-3394. Nouchkana chon angangen Customer Support iir mei tongeni anisuk fansoun meinsin kopwe need aninis. Ika pwun kopwe nikitativ porous faniten kose tourngeni ion kopwe ururun porous ngeni, chechemeni kopwe pwan nikitativ nampan om area code, nampan noun foon, me unusen itom pwun sipwe tongeni korsefanuk.

Nenien Aninis

Kose mochen nongeni www.smartstartinc.com om kopwe kuna ekkena nenien service an Smart Start mei kanengonuk.

Technical Data

Sensor	Electrochemical (Fuel Cell)
Epwe Ifa Ussun Isoisen me om Nounou ei Pisek	Tempuchu: -40°F to 185°F (-40°C to + 85°C) Pwichipwichin: 20% to 98% r.h. Pressure: 70 to 110 kPa Esapw wor met epwe ekeswini tekian me won ewe pwungun measurement
Protection Class	IP42
Timen Ammanaw ika Epwichipwich	watteseni 68°F / 20°C < 25 seken me non -40°F / -40°C < 3 minich
Koukun ika Watten Samplun Angasangas	Me Non Amaat, Epwe tongeni Achas
Met Pwungupwungun	PASS, WARN, FAIL, VIOL Numerical: %BAC, mg/L
Esinesin mi Pichita	Mak mi Pichita Fengen me Tengkiei Mei Ruu Enuwanges
Esinesin Mei Okurang	Speaker mi Tiik
Sais	Chamwan: 4.8 x 2.6 x 1.8 in. (123 x 67 x 45 mm) Relay Unit: 5.9 x 3.5 x 1.4 in. (150 x 90 x 35 mm)
Choun	Chamwan: 5.6 oz. (160 grams) Relay Unit: 10.5 oz. (300 grams)
Voltage nupwen mi Ammanaw	Nampa: Esapw Kiseseni 12 VDC: 6.5 VDCsapw Kiseseni 12
Ofian Fiifi	Napenon: < 4 A Stand-by: < 5 mA
Koukun Met e Tou	15 A continuous 40 A tekian
Setifiket	NHTSA Model Tichikin ren BAIDs: 2013 CSA Z627-16: 2016 EN 50436-1:2014, EN 50436-2:2014 E-Mark

Table 2 SSI-2035 Technical Data

Ignition Interlock Hawaii Client Checklist

****Kose mochen makkei ewin mesenimakken itom me om last name won ekkei line an epwe pwarata pwun en mi weweiti met ururun kopwe fori meren Smart Start****

- _____ Uwa katon ewe videon kait.
- _____ Uwa angei copyn nei taropwe mi afatatiw met upwe fori meren Smart Start LLC iwe ngang mi weweiti masowen ekkei mettoch mi afateti.
- _____ Ewe taropwen etipeeu faniten ei fansoun upwe annomwu ei pisek meren Smart LLC mi aweweochuto iwe ngang mi pwan weweochuti.
- _____ Ewe kinikin e porous faniten warranty ika tumunun taan ei pisek mi pwan aweweochuto.
- _____ Ngang mi weweiti me etiwa masowen ei lease, warranty, me afatetiwen instructions, porous faniten removal me ekkewe kait mi maketi meren ekkewe chon pachei me fori ei pisek pwan met mi mak non ewe taropwen etipeeu.
- _____ Iir mei aiteochungeniei nounouechun ei ignition interlock me won waai.
- _____ Ngang mi weweiti pwun ika use passini ew test, upwe pwan angeisefanni pwan ew test.
- _____ Ngang mi weweiti pwun ai nounoungaw ika angangen atai ei pisek, ren ai upwe omwokutu, eppet, ika pwonuu ewe camera (pwan pachonong ai upwe aa och mettoch ne pwonuu ei pisek, ussun ew cup) ika ai upwe pwan fichi senin me wean ei ignition interlock, pwan met monukun, mi nom non tikin circumvention/ ika osukosuka ei pisek fan ewe kinikin 291E-66 HRS iwe mei tongeni wor ai tipis non kopwung. Epwe wor esinesin ngeni ion e masamas won ena pisek rei.
- _____ Ngang mi weweiti pwun ai utti ewe chamwen ei pisek nukanapen ai unteng mi pwan nom non tikin circumvention iwe ngang mi tongeni tipis non kopwung ren. Epwe wor esinesin ngeni ion e masamas won ena pisek rei.
- _____ Ngang mi weweiti pwun ese nifinifin ion epwe tongeni uwei wai, nge repwe pwan kaeo nounoun ei pisek, iwe ngang upwe masamas won meinisin pwungun test mi nom non ei pisekin test.
- _____ Ngang mi weweiti pwun ika ngang chon unteng, ai ngeni emon epwe wisen angei ei test fanitei mi pwan nom non tikin circumvention iwe mi pwan tongeni fis pwun ai tipis non kopwung faniten circumvention faan ewe kinikin 201E-66 me 291E-67, HRS. Epwe wor esinesin ngeni ion e masamas won ena pisek rei.
- _____ Ngang mi weweiti pwun upwe tumuneochu ai unteng nupwen u nounou ei pisek. Ngang mi pwan weweiti pwun ekan onuu (6) minich ai upwe awesii ew re-test iwe mi eureur ngeniei ai upwe kouno nepekin aan atun eseor osukosuk me met epwe tongeni osukosukaei won aan ai upwe angei ena re-test.
- _____ Ngang mi weweiti pwun upwe uwei nei ID mi fiti sasing atun ai appointmentin pachepachetan ei pisek. Ngang mi weweiti pwun upwe apply ngeni ew ignition interlock permit meren ADLRO ika a pacheta ewe pisek nefon waai.
- _____ Mi Eureur ngeniei ai usapw mongo, uun, ika uun supwa nupwen upwe test iwe ngang mi pwan weweiti pwun upwe uun konik mwemwen upwe angasangasa ei test an epwe nimetau met epwe tongeni osukosuka ei test.
- _____ Ngang mi weweiti pun ngang mi tongeni uwei waiei ne no for sefan ika calibrate me non ese nifinifin nein ekkewe nenien service an Smart Start me non Hawaii.
- _____ Ngang upwe omwochu ika anomwu woi echoID mi fiti sasing u angei seni mwuu ika kafemen gnition Interlock Permit nupwen upwe unteng won epoch waa mi wor efoch ignition interlock nefon ai upwe saa won anen mwuu.
- _____ Ngang mi sinei pwun upwe kokori 1-800-880-3394 ika e wor ai kapaseis. Om minne kopwe aa ei pisek nenien Sainei.

Om minne kopwe aa ei pisek nenien Sainei itom _____ Raan ika Teiten ikenai _____

Makketiw itom minne kopwe aa ei pisek _____ Raanin om upwutiw _____

Nenien an Chon Fori ika Apacha ei Pisek Sainei itan _____ Raan ika Teiten Ikenai _____

Nenien ei Service _____

SMART START, LLC
500 E Dallas Road Suite 100 • Grapevine, TX 76051
1-800-880-3394 • SmartStartInc.com

Smart Start, Inc. ese asokonoi an aninis ngeni aramas fan iten ian re feito me ia, aar namanam, ika iir fefin ika mwan, me meni fonu re wareseni.

ESINESINEN EPWENE ETITIW EWE PISEK

Smart Start ekōnaan lewaj an kamooolol eok kin am bejnejj ibbam. Einwōt juon kein kōkememejj, Smart Start ekonaan bar kokememejj eok ke ñe kwonaj komakuti mejin in lak eo an wa eo waan mokta jen an jemlok ien kabojrak laiijen in kattor eo am, ejab melim am kattore wa eo ilo an jab elāk mejin in lak eo ekkar nan Kakien ko Emojj Kokkaal Kobbān Melele an Hawaii. Ilo ien am kattore juon wa ilo an wor am peba in komelim mejin in lak ilo an ejellok juon mejin in lak eo an wa ej elāk emaron jemlok ilo an wor kaje ko jet ikijen ruprup kakien ko relab. Ilo ien emoj am komakuti mejin eo, juon ripoot in emakut enaj komman im etal nan Ra eo ej lale Kakien ko an lal ilo Ene, Mejatoto, im Lojet an Hawaii (Hawaiiit Department of Transportation), opij eo ej lale Burokraam in Mejin in Lak eo an Wa ilo Hawaii. Elane ewor jabdewot am kajjitok ikijen mejin in lak jout eo kebaak Smart Start ilo (808)695-2416 im/ak loar eo am.

Uwa aneani pwan weweiti metekei mi afatetiw asan.

Makketiw Itom

Raanin Ikenai

Sainei Itom